


## FEEDALL Model 1700-D Magazine Bar Feeder w/1650-1SC-84 Cross-Feed Conveyor



**APPLICATION:** Feed from a manually loaded, floor mounted magazine. Shafts will be fed in a continuous stream and escaped one at a time onto a front mounted cross-feed conveyor. The conveyor will translate parts in a continuous stream to the workrest of a CINCINNATI centerless grinder.

**WIDTH:** 4"-36" (Adjustable)

**DRIVE:** 1/4 HP/AC Motor w/Variable Frequency Controller

**PARTS FED (SIZE):** Shafts (0.50"-1.25"Ø x 4.00"-36.00" Lg.)

**FEED RATE:**

**MACHINE FED:** CINCINNATI Centerless Grinder